



DATA SHEET

INFINITY HEXAGONAL 125x45x18 mm




Mesh orientation on the panel.



Signification	material	LWD	SWD	A	E	B	weight	open area
		mm	mm	mm	mm	mm	kg/m ²	%
Infinity	aluminium	125	45	18	17	1,5	3,21	26
Infinity	aluminium	125	45	18	17	2	4,32	26
Infinity	steel	125	45	18	17	1,5	9,42	26
Infinity	steel	125	45	18	17	2	12,56	26

Description of expanded metal

LWD x SWD x A x B



LWD = long way diagonal / SWD = short way diagonal / A = strand width / B = thickness / C = width of plate / D = length of plate / E = total thickness

The figure for the corrected height of the drawbar is for guidance only.

This value is measured at the center of the panel, with the value on the sides of the panel always being higher.

Light transmittance

